
## **READ THIS DOCUMENT**

## **LUXINTEC**

### INSTALLATION, OPERATION, MAINTENANCE AND RECYCLING INSTRUCTIONS

#### **PACKAGING CONTENT**



Thank you for purchasing a LUXINTEC luminaire with high performance and durability, and environmental friendly.

### **PRECAUTIONS**

- 1. Disconnect the power supply to the cable before the installation and maintenance of the product.
- 2. All installation and maintenance operations must be done by a qualified electrician.
- The installation, operation, maintenance and recycling of the product must be carried out while complying with the applicable rules and guidelines. An electric technician must issue a declaration of conformity of the installation with those rules and guidelines.
- All the connections must be protected by connectors and/or cable insulators standardized for the application.
- 5. The installation, location and operation of the product must be carried out in a way that all the parameters specified in the label and documentation delivered with the product are met. If this information cannot be found, do not proceed with its installation and contact LUXINTEC.
- 6. Keep this document for future reference.
- 7. The pictures are for reference, they may not coincide exactly with the product received.

#### **LOCATIONS**

- 8. Interior or exterior of buildings under cover.
- 9. Ventilated spaces and always used for people activities.

#### **OPERATION**

- 10. Connect the luminaire to mains voltage in the range indicated on the product labelling.
- 11. The product can only be connected to an electrical line with protections against voltage peaks, overvoltages and harmonics free.
- 12. The ambient temperature around the luminaire must not exceed the indicated values on the product labelling. The service life of the luminaire is reduced by increasing the temperature above 25°C.
- 13. If the luminaire tightness degree is <IP66, it must be installed in places with a humidity lower tan 70%.
- 14. Except as otherwise indicated in other product documentation, this product is not indicated for use in atmospheres with chemical, corrosive or explosive elements.

### **LUXINTEC**

### MAINTENANCE

- 15. Use only dry dusters, water or neutral degreasers to clean the product, the use of other chemical substances could damage it.
- 16. In case of need for repair, contact LUXINTEC to receive appropriate instructions for each type of repair.


### RECYCLING

- 17. After using the product do not throw it away and deliver it to an approved waste manager following the local guidelines or regulations.
- 18. Packaging material is reciclable. To dispose it, previously separate the elements of paper, plastic and metals, placing them in specific recycling containers for each type of material.

#### LIABILITY AND GUARANTEE

- 19. LUXINTEC, S.L. is exempt from all liability arising from the incorrect installation, location, operation, maintenance and recycling of the product.
- 20. LUXINTEC, S.L. guarantees the product only if:
  - 1. it is fed by a power supply provided by LUXINTEC.
- 2. its installation and operation complies with the instructions described on this document. 21. The general guarantee terms of the product are available at <a href="https://www.luxintec.com">www.luxintec.com</a>.
- Position the luminaire (1) in the track 2 according to the mounting direction of the adapter. Attention! It can only be installed in one direction 2 Insert the luminaire adapter (3) into the track (2). Previously disconnect the network voltage. 3 2 2 Rotate the adapter anchor tab 4 until it is positioned in the direction of the track (2). If the luminaire is DALI rotate the rear anchor tab (5) of the adapter.

### **LUXINTEC**



**NOTE**: To move the luminaire on the electrified track or to change the phase, previously make sure that the track has not network voltage.

Thanks for trusting on LUXINTEC.

If you have any question about the installation, operation, maintenance or recycling of the luminaire, call the phone +34 983 130 056 or send us an email to luxintec@luxintec.com.

# **LUXINTEC**